


DHC4900 / DHC4200 / DHC4500

DHC4900 / DHC4200 / DHC4500



STOCK CODE	DESCRIPTION	MAN.PART NUMBER	DRAWING REF
XDHC1000	DISPLAY CABINET - HALOGEN GLOBE	1206010007	1
XDHC1001	DISPLAY CABINET - SHELF BRACKET - FOR DHC4900	2220030016	2
XDHC1004	DISPLAY CABINET - TOP SHELF - FOR DHC4900	1220010013	3
XDHC1010	DISPLAY CABINET - FAN	1204030004	7
XDHC1011	DISPLAY CABINET - ELEMENT	1206020001	8
XDHC1014	DISPLAY CABINET - TRANSFORMER - FOR DHC4900		9
XDHC1017	DISPLAY CABINET-ROCKER SWITCH (NON ILLUMINATE)	1205020002	11
XDHC1018	DISPLAY CABINET-ROCKER SWITCH (ILLUMINATED)	1205020003	12
XDHC1019	DISPLAY CABINET- CONTROLLER	2220251001	14
XDHC1020	DISPLAY CABINET- CONTROLLER BOARD	1103050036	15
XDFC0081	DISPLAY CABINET-FRONT GLASS 900MM	A220152010	4
XDFC0084	DISPLAY CABINET-SIDE GLASS LH	A220141007	
XDFC0085	DISPLAY CABINET-SIDE GLASS RH	A220141008	
XDFC0086	DISPLAY CABINET- REAR SLIDING GLASS L / R	A220170007	16

XDHC1000	DISPLAY CABINET - HALOGEN GLOBE	1206010007	1
XDHC1002	DISPLAY CABINET - SHELF BRACKET - FOR DHC4200	2220030017	2
XDHC1005	DISPLAY CABINET - TOP SHELF - FOR DHC4200	1220010014	3
XDHC1010	DISPLAY CABINET - FAN	1204030004	7
XDHC1012	DISPLAY CABINET - ELEMENT-FOR DHC4200	1206020001	8
XDHC1015	DISPLAY CABINET - TRANSFORMER - FOR DHC4200		9
XDHC1017	DISPLAY CABINET-ROCKER SWITCH (NON ILLUMINATE)	1205020002	11
XDHC1018	DISPLAY CABINET-ROCKER SWITCH (ILLUMINATED)	1205020003	12
XDHC1019	DISPLAY CABINET- CONTROLLER	2220251001	14
XDHC1020	DISPLAY CABINET- CONTROLLER BOARD	1103050036	15
XDFC0082	DISPLAY CABINET-FRONT GLASS 1200MM	A220152011	4
XDFC0084	DISPLAY CABINET-SIDE GLASS LH	A220141007	
XDFC0085	DISPLAY CABINET-SIDE GLASS RH	A220141008	
XDFC0087	DISPLAY CABINET- REAR SLIDING GLASS L / R	A220170008	16

XDHC1000	DISPLAY CABINET - HALOGEN GLOBE	1206010007	1
XDHC1003	DISPLAY CABINET - SHELF BRACKET - FOR DHC4500	2220030018	2
XDHC1006	DISPLAY CABINET - TOP SHELF - FOR DHC4500	1220010015	3
XDHC1010	DISPLAY CABINET - FAN	1204030004	7
XDHC1013	DISPLAY CABINET - ELEMENT - FOR DHC4500	1206020001	8
XDHC1016	DISPLAY CABINET - TRANSFORMER - FOR DHC4500		9
XDHC1017	DISPLAY CABINET-ROCKER SWITCH (NON ILLUMINATE)	1205020002	11
XDHC1018	DISPLAY CABINET-ROCKER SWITCH (ILLUMINATED)	1205020003	12
XDHC1019	DISPLAY CABINET- CONTROLLER	2220251001	14
XDHC1020	DISPLAY CABINET- CONTROLLER BOARD	1103050036	15
XDFC0083	DISPLAY CABINET-FRONT GLASS 1500MM	A220152012	4
XDFC0084	DISPLAY CABINET-SIDE GLASS LH	A220141007	
XDFC0085	DISPLAY CABINET-SIDE GLASS RH	A220141008	
XDFC0088	DISPLAY CABINET- REAR SLIDING GLASS L / R	A220170009	16