


06 cleaning & washing


GWD1000



01_005_e

STOCK CODE	DESCRIPTION	MAN.PART NUMBER	DRAWING REF
XGWD0030	GLASS WASHER DIHR - O-RING	13305	30
XGWD0035	GLASS WASHER DIHR - S/STEEL NUT	11701/A	35
XDWD0851	DISHWASHER DIHR-PLASTIC FOOT (GS40/50)	10850	40
XGWD0006	GLASS WASHER DIHR(NEW)-OVERFLOW PIPE	135252	45
XDWD0701	DISHWASHER DIHR-DRAIN ELBOW (GS45/50)	10701	50
XDWD0714	DISHWASHER DIHR-BOILER ELEMENT (DERBY)	10714	55
XGWD0115	GLASS WASHER DIHR-S/STEEL FILTER FOR DRAIN PUMP	440751	115
XGWD0120	GLASS WASHER DIHR - BRACKET FOR FILTER	11701/B	120

GWD1000





03_012_e

STOCK CODE	DESCRIPTION	MAN.PART NUMBER	DRAWING REF
XDWD0711	DISHWASHER DIHR-PILOT LIGHT	10711/B	4240
XDWD5813	DISHWASHER DIHR-UNIPOLAR SWITCH 16A GS50	15813	4250
XDWD2003	DISHWASHER DIHR-16A SWITCH (HT11) DEVIATOR	15812	4255
XDWD2007	DISHWASHER DIHR-16A BIPOLAR SWITCH (HT11)	15800	4257
XDWD2004	DISHWASHER DIHR-16A BIPOLAR SWITCH	15811	4260
XDWD4040	DISHWASHER DIHR- PILOT LIGHT(HT11)	15826	4275

06 cleaning & washing


GWD1000



03_059_e

STOCK CODE	DESCRIPTION	MAN.PART NUMBER	DRAWING REF
XDWD2007	DISHWASHER DIHR-16A BIPOLAR SWITCH (HT11)	15800	44245
XDWD2004	DISHWASHER DIHR-16A BIPOLAR SWITCH	15811	44250
XDWD5813	DISHWASHER DIHR-UNIPOLAR SWITCH 16A GS50	15813	44255
XDWD4040	DISHWASHER DIHR- PILOT LIGHT(HT11)	15826	44266

GWD1000



STOCK CODE	DESCRIPTION	MAN.PART NUMBER	DRAWING REF
XDWD3003	DISHWASHER DIHR-O-RING 112 (11S)WASH ARM	13003	2305
XDWD1002	DISHWASHER DIHR-GASKET (GS40)	13002	2320
XGWD0001	GLASS WASHER DIHR (DERBY) - RINSE JET	10371	2335
XDWD1372	DISHWASHER DIHR-RINSE NOZZLE CLOSE(GS40)	10372	2340
XDWD3319	DISHWASHER DIHR-SLIDING WASHER (GS50)	13319	2345
XGWD0005	GLASS WASHER DIHR(DERBY/GS40)-UPPER WASH ARM	10997	2360
XGWD0004	GLASS WASHER DIHR(DERBY)-LOWER WASH ARM	10999	2365

17_001ae